

Metal T-Handle

for Andersen® Casement and Awning Windows



INSTALLER: Please leave this guide with the building owner to file for future reference.

Congratulations! You have just purchased one of the many fine Andersen® products. For ease of installation and continued enjoyment of your Andersen product, please read and follow this Instruction Guide completely. If your abilities do not match this procedure's requirements contact an experienced contractor. You may direct any questions about this or other products to your local Andersen dealer. Andersen dealers can be found in the Yellow Pages under Windows. Thank you for choosing Andersen.

Important Safety Information

Children are very observant and at a young age will mirror the actions of their parents and siblings, such as unlocking and opening a window. Opening a window for children (5 and under) could pose a risk to their safety. The Metal T-Handle is an accessory device that may make it more difficult for young children (5 and under) to open a window. Windows are used for escape and rescue in an emergency such as a fire, and must remain operational at all times. Once your children reach an age where they fully understand how to properly interact with the windows in your home, reapply the handle. Teach your children how to properly interact with a window and how to use it for an emergency escape.

Installation Tools and Supplies Needed:

- Safety Glasses
- No. 2 Phillips screwdriver

1. Remove and Install Handles

⚠ WARNING

Improper use of screwdriver could result in personal injury and/or product damage. Follow equipment manufacturer's instructions for safe operation. Always wear safety glasses.

- Remove *Existing Handle* by loosening set screw.
- Place new *Metal T-Handle* on operator stud and fasten by tightening set screw.

