

BAY & BOW WINDOWS



Custom sized in 1/8" (3) increments between minimum and maximum width and height dimensions.

In addition to venting shown in tables, other standard configurations are available.

Choose left venting, right venting or stationary as viewed from the exterior.

Measurement guide can be found at andersenwindows.com/measure.

Custom Casement 30° Angle Bay Window Size and Projection Range

Sash Ratio Window Configuration	Center Window Venting Configuration	Window Dimension			Projection			
		Minimum Width Inches/(mm)	Maximum Width Inches/(mm)	Minimum Height Inches/(mm)	Maximum Height Inches/(mm)	Minimum Inches/(mm)	Maximum Inches/(mm)	
1:1:1 	Venting or Stationary 	50" (1270)	101 1/2" (2578)	X	26 1/8" (664)	73 7/8" (1876)	10 1/4" (260)	19 5/8" (498)
1:2:1 	Venting or Stationary 	67 3/8" (1711)	137 1/2" (3493)	X	26 1/8" (664)	73 7/8" (1876)	10 1/4" (260)	19 5/8" (498)
1:2:1 	Picture 	70 7/8" (1800)	115 1/4" (2927)	X	38" (965)	73 7/8" (1876)	10 3/4" (273)	16 5/8" (422)
		115 1/4" (2927)	137 5/8" (3496)	X	38" (965)	61 7/8" (1571)	16 5/8" (422)	19 5/8" (498)
1:3:1 	Venting or Stationary 	84 1/2" (2146)	144" (3658)	X	26 1/8" (664)	73 7/8" (1876)	10 1/4" (260)	16 1/2" (419)
1:3:1 	Picture 	83 7/8" (2130)	97 7/8" (2486)	X	38" (965)	73 7/8" (1876)	10 1/4" (260)	11 5/8" (295)
		97 7/8" (2486)	116 7/8" (2969)	X	38" (965)	61 7/8" (1571)	11 5/8" (295)	13 5/8" (346)

Custom Casement 45° Angle Bay Window Size and Projection Range

Sash Ratio Window Configuration	Center Window Venting Configuration	Window Dimension			Projection			
		Minimum Width Inches/(mm)	Maximum Width Inches	Minimum Height Inches/(mm)	Maximum Height Inches/(mm)	Minimum Inches/(mm)	Maximum Inches/(mm)	
1:1:1 	Venting or Stationary 	45 3/4" (1162)	91 1/4" (2318)	X	26 1/8" (664)	73 7/8" (1876)	14 3/16" (360)	27 1/2" (699)
1:2:1 	Venting or Stationary 	63" (1600)	127 1/4" (3232)	X	26 1/8" (664)	73 7/8" (1876)	14 1/4" (362)	27 1/2" (699)
1:2:1 	Picture 	66" (1676)	106 7/8" (2715)	X	38" (965)	73 7/8" (1876)	14 7/8" (378)	23 1/4" (591)
		106 7/8" (2715)	127 1/4" (3232)	X	38" (965)	61 7/8" (1571)	23 1/4" (591)	27 1/2" (699)
1:3:1 	Venting or Stationary 	80 1/8" (2035)	144" (3658)	X	26 1/8" (664)	73 7/8" (1876)	14 1/4" (362)	24 7/16" (618)
1:3:1 	Picture 	79 5/8" (2023)	92 3/4" (2356)	X	38" (965)	73 7/8" (1876)	14 3/16" (360)	16 1/4" (413)
		92 3/4" (2356)	110 3/8" (2804)	X	38" (965)	61 7/8" (1571)	16 1/4" (413)	19" (483)

WARNING

Proper support of projecting bow and bay windows is required, see installation guidelines. Failure to do so may result in injury, product damage and/or property damage.

- "Projection" refers to outside of the exterior sheathing to the outer edge of the window.
- "Window Dimension" always refers to outside frame to frame dimension.
- **"Minimum Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.**
- One Andersen cable kit is included with the unit for proper installation. Each cable supports a maximum load of 500 lbs. or 227 kg; additional support is necessary for loads exceeding 500 lbs. or 227 kg.
- Angle bay and bow windows include only the basic unit. Roof and other installation materials provided by other manufacturers.
- For walkout angle bay and bow window details and installation guidelines, contact your Andersen supplier or visit our website at andersenwindows.com/adf.
- Refer to andersenwindows.com/measure for detailed instructions on how to properly measure for custom-size windows.
- Dimensions in parentheses are in millimeters.



Custom sized in 1/8" (3) increments between minimum and maximum width and height dimensions.

In addition to venting shown in tables, other standard configurations are available.

Choose left venting, right venting or stationary as viewed from the exterior.

Measurement guide can be found at andersenwindows.com/measure.

Custom Casement 90° Box Bay Window Size and Projection Range

Window Configuration	Center Window Venting Configuration	Window Dimension				Flanker		Projection		
		Minimum Width Inches/(mm)	Maximum Width Inches/(mm)	Minimum Height Inches/(mm)	Maximum Height Inches/(mm)	Minimum Width Inches/(mm)	Maximum Width Inches/(mm)	Minimum Depth Inches/(mm)	Maximum Depth Inches/(mm)	
	Picture	38 1/4" (972)	61 7/8" (1572)	X	38" (965)	73 7/8" (1876)	17" (432)	35 7/8" (911)	21 1/2" (546)	40 3/8" (1026)
	Picture	61 7/8" (1572)	74 1/8" (1883)	X	38" (965)	61 7/8" (1572)	17" (432)	35 7/8" (911)	21 1/2" (546)	40 3/8" (1026)
	Venting or Stationary	36 3/8" (924)	74 1/4" (1886)	X	26 1/8" (664)	73 7/8" (1876)	17" (432)	35 7/8" (911)	21 1/2" (546)	40 3/8" (1026)
	Picture	53 1/2" (1359)	110 3/8" (2804)	X	26 1/8" (664)	73 7/8" (1876)	17" (432)	35 7/8" (911)	21 1/2" (546)	40 3/8" (1026)

Custom Casement 10° Bow Window Size and Projection Range

Window Configuration	Center Window Venting Configuration	Window Dimension				Projection		
		Minimum Width Inches/(mm)	Maximum Width Inches/(mm)	Minimum Height Inches/(mm)	Maximum Height Inches/(mm)	Minimum Depth Inches/(mm)	Maximum Depth Inches/(mm)	
3-Wide	Venting or Stationary	52 1/2" (1334)	108 7/8" (2765)	X	26 1/8" (664)	73 7/8" (1876)	4 3/8" (111)	7 5/8" (194)
4-Wide	Venting or Stationary	69 1/2" (1765)	143 7/8" (3654)	X	26 1/8" (664)	73 7/8" (1876)	7 3/8" (187)	13 7/8" (352)
5-Wide	Venting or Stationary	85 7/8" (2181)	164 1/4" (4172)	X	26 1/8" (664)	73 7/8" (1876)	10 3/8" (264)	18 5/8" (473)
6-Wide	Venting or Stationary	101 5/8" (2581)	164 1/4" (4172)	X	26 1/8" (664)	73 7/8" (1876)	14 7/8" (378)	23 3/16" (589)
7-Wide	Venting or Stationary	116 5/8" (2962)	164 1/4" (4172)	X	26 1/8" (664)	73 7/8" (1876)	19 3/16" (487)	26 3/8" (670)

⚠ WARNING

Proper support of projecting bow and bay windows is required, see installation guidelines. Failure to do so may result in injury, product damage and/or property damage.

- "Projection" refers to outside of the exterior sheathing to the outer edge of the window.
- "Window Dimension" always refers to outside frame to frame dimension.
- **"Minimum Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.**
- One Andersen cable kit is included with the unit for proper installation. Each cable supports a maximum load of 500 lbs. or 227 kg; additional support is necessary for loads exceeding 500 lbs. or 227 kg.
- Angle bay and bow windows include only the basic unit. Roof and other installation materials provided by other manufacturers.
- For walkout angle bay and bow window details and installation guidelines, contact your Andersen supplier or visit our website at andersenwindows.com/adf.
- Refer to andersenwindows.com/measure for detailed instructions on how to properly measure for custom-size windows.
- Dimensions in parentheses are in millimeters.